

# Dahl Docking Station - MK II System

## Vehicle list - tested fitting kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	For b-pillar			MK II	
				Amount docking stations	Seat base	Shoulder belt anchorage		
Citroën	Berlingo, Tripod/allied dropfloor conversion	B	/	2	1	1	503461	
		C	surface				502171	
	Jumper Y	C	flush				502172	
		W	surface				502179	
		W	flush				502180	
	Jumpy X	C	surface				502171	
		C	flush				502172	
		RD	surface				502177	
	Jumpy & Spacetourer KO, Freedom Drop Floor Conversion	RD	flush				502178	
		B		1	0	0	503303	
		B		1	0	1	503304	
	Fiat	Doblo high roof SWB & LWB	B		2	1	0	503305
			B		2	1	2	503306
			C	surface				503302
		Ducato X250	C	flush				503301
D			surface				503121	
D			flush				503120	
Scudo X270		C	surface				502171	
		C	flush				502172	
		RD	surface				502177	
		RD	flush				502178	
		C	surface				502171	
		C	flush				502172	
Talent		C	surface				502171	
		C	flush				502172	
		C	surface				502171	
	C	flush				502172		
Ford	Transit Custom V362	C	surface				502171	
		C	flush				502172	
	RD	surface				502177		
	RD	flush				502178		
MAN	Transit V363	C	surface				502194	
	TGE 2017-	C	surface				503142	
		C	flush				503143	
		W	surface				503145	
		W	flush				503144	
Mercedes	Vito & V-Class W447	D	surface				502171	
		D	flush				502172	
		B		2	1	2	502163	
		B		2	1	0	502164	
		B		1	0	1	502165	
	Sprinter 906 & 907	B		1	0	1	502166	
		B		1	0	0	502167	
		B		1	0	0	502168	
		C	surface				502171	
		C	flush				502172	
	Sprinter 910	RD	surface				502177	
		RD	flush				502178	
		B		2	1	2	501970	
		B		1	0	1	501971	
		B		2	1	0	502034	
B			1	0	0	502035		
W		surface				502175		
W		flush				502176		
D		surface				502171		
D		flush				502172		
Nissan	NV 200	W	surface				503197	
		C	surface				502171	
	NV 300	C	flush				502172	
		D	surface				502171	
		D	flush				502172	
	NV 400	B		2	1	2	502039	
		B		2	1	0	502041	
		B		1	0	1	502042	
		B		1	0	0	502043	
		C	surface				502181	
	Primastar	C	flush				502182	
		C	surface				502171	
		C	flush				502172	
		D	surface				503121	
		D	flush				503120	
Opel	Combo High roof SWB & LWB	B		2	1	2	502039	
		B		2	1	0	502041	
	B		1	0	1	502042		
	B		1	0	1	502042		

SYMBOLS: B-pillar = B / C-pillar = C / D-pillar = D / Window frame = W / Rear door = RD

# Dahl Docking Station - MK II System

## Vehicle list - tested fitting kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	For b-pillar			MK II	
				Amount docking stations	Seat base	Shoulder belt anchorage		
Citroën	Berlingo, Tripod/allied dropfloor conversion	C	surface				502181	
		C	flush				502182	
	Vivaro X 82 & X 83	C	surface				502171	
		C	flush				502172	
		D	surface				502171	
	Jumper X	D	flush				502172	
		C	surface				502171	
		C	flush				502172	
	Peugeot	Boxer Y	RD	surface				502177
			RD	flush				502178
			B		1	0	0	503303
		Expert X	B		1	0	1	503304
			B		2	1	0	503305
	Fiat	Doblo high roof SWB & LWB	B		2	1	2	503306
			C	surface				503302
C			flush				503301	
Ducato X250		C	surface				503301	
		D	surface				503121	
		D	flush				503120	
Scudo X270		C	surface				502171	
		C	flush				502172	
		RD	surface				502177	
		RD	flush				502178	
		C	surface				502171	
		C	flush				502172	
Talent		C	surface				502171	
		C	flush				502172	
		C	surface				502171	
	C	flush				502172		
Ford	Transit Custom V362	C	surface				502171	
		C	flush				502172	
	RD	surface				502177		
	RD	flush				502178		
MAN	Transit V363	C	surface				502194	
	TGE 2017-	C	surface				503142	
		C	flush				503143	
		W	surface				503145	
		W	flush				503144	
Mercedes	Vito & V-Class W447	D	surface				502171	
		D	flush				502172	
		B		2	1	2	502163	
		B		2	1	0	502164	
		B		1	0	1	502165	
	Sprinter 906 & 907	B		1	0	1	502166	
		B		1	0	0	502167	
		B		1	0	0	502168	
		C	surface				502171	
		C	flush				502172	
	Sprinter 910	RD	surface				502177	
		RD	flush				502178	
		B		2	1	2	501970	
		B		1	0	1	501971	
		B		2	1	0	502034	
B			1	0	0	502035		
W		surface				502175		
W		flush				502176		
D		surface				502171		
D		flush				502172		
Nissan	NV 200	W	surface				503197	
		C	surface				502171	
	NV 300	C	flush				502172	
		D	surface				502171	
		D	flush				502172	
	NV 400	B		2	1	2	502039	
		B		2	1	0	502041	
		B		1	0	1	502042	
		B		1	0	0	502043	
		C	surface				502181	
	Primastar	C	flush				502182	
		C	surface				502171	
		C	flush				502172	
		D	surface				503121	
		D	flush				503120	
Opel	Combo High roof SWB & LWB	B		2	1	2	502039	
		B		2	1	0	502041	
	B		1	0	1	502042		
	B		1	0	1	502042		

SYMBOLS: B-pillar = B / C-pillar = C / D-pillar = D / Window frame = W / Rear door = RD