

Dahl Docking Systems - MK II & VarioDock™

List of vehicles with approved installation kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	For b-pillar			MK II	Vario	FMVSS 207/ CMVSS 207	FMVSS 210/ CMVSS 210		
				Amount docking stations	Seat base	Shoulder belt anchorage						
Citroën	Berlingo, Tripod/allied dropfloor conversion Jumper Y	B	/	2	1	1	503461	503954				
		C	surface				502171	503920				
		C	flush				502172	503921				
		W	surface				502179	503928				
		W	flush				502180	503929				
	Jumpy X	C	surface				502171	503920				
		C	flush				502172	503921				
		RD	surface				502177	503926				
	Jumpy & Spacetourer KO, Freedom Drop Floor Conversion	RD	flush				502178	503927				
		B		1	0	0	503303	503950				
		B		1	0	1	503304	503951				
		B		2	1	0	503305	503952				
		B		2	1	2	503306	503953				
	Jumpy & Spacetourer KO	C (middle)	surface					503665				
		C	surface				503302	503949				
C		flush				503301	503946					
Fiat	Doblo high roof SWB & LWB	D	surface				503121	503940				
		D	flush				503120	503939				
	Ducato X250	C	surface				502171	503920				
		C	flush				502172	503921				
		W	surface				502179	503928				
	Scudo X270	W	flush				502180	503929				
		C	surface				502171	503920				
		C	flush				502172	503921				
	Talento 2016-	RD	surface				502177	503926				
		RD	flush				502178	503927				
		C	surface				502171	503920				
		C	flush				502172	503921				
		D	surface				502171	503920				
	Ford	Transit Custom V362	D	flush				502172	503921			
			C	surface				502171	503920			
C			flush				502172	503921				
Transit V363		RD	surface				502177	503926				
		RD	flush				502178	503927				
Jeep MAN	Renegade, ACA Drop floor conversion	C	surface	2	1	0	501551	501552				
	TGE 2017-	C	flush				503142	503941				
Mercedes	Vito & V-Class W447	C	surface				503143	503942				
		W	surface				503145	503944				
		W	flush				503144	503943				
		D	surface				502171	503920				
		D	flush				502172	503921				
		B		2	1	2	502163	503914				
		B		2	1	0	502164	503915				
		B		1	0	1	502165	503916				
		B		1	0	1	502166	503917				
		B		1	0	0	502167	503918				
Mitsubishi	Express (Australien & New Zealand)	B		1	0	0	502168	503919				
		C	surface				502171	503920				
		C	flush				502172	503921				
		RD	surface				502177	503926				
		RD	flush				502178	503927				
		Sprinter 906 & 907 & 910	B		2	1	2	501970	503902	√	√	
			B		1	0	1	501971	503903	√	√	
			B		2	1	0	502034	503905	√	√	
		Nissan	NV 200 NV 300	B		1	0	0	502035	503906	√	√
				W	surface				502175	503924		√
				W	flush				502176	503925		√
				D	surface				502171	503920		
				D	flush				502172	503921		
				D	flush				502177	503926		
		Nissan	NV 400	D	flush				502171	503920		
D	surface						502172	503921				
D	flush						502177	503926				
D	flush						502172	503921				
W	surface						503197	503945				
C	surface						502171	503920				
C	flush						502172	503921				
D	surface						502171	503920				
D	flush						502172	503921				
D	flush						502177	503926				
Opel	Combo High roof SWB & LWB	B		2	1	2	502039	503909				
		B		2	1	0	502041	503911				
		B		1	0	1	502042	503912				
		B		1	0	0	502043	503913				
		C	surface				502181	503930				
		C	flush				502182	503931				
		C	surface				502171	503920				
		C	flush				502172	503921				
		D	surface				502171	503920				
		D	flush				502172	503921				
Opel	Movano X 62	D	surface				503121	503940				
		D	flush				503120	503939				
		B		2	1	2	502039	503909				
		B		2	1	0	502041	503911				

Dahl Docking Systems - MK II & VarioDock™

List of vehicles with approved installation kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	For b-pillar			MK II	Vario	FMVSS 207/ CMVSS 207	FMVSS 210/ CMVSS 210
				Amount docking stations	Seat base	Shoulder belt anchorage				
		B		1	0	1	502042	503912		
		B		1	0	0	502043	503913		
		C	surface				502181	503930		
		C	flush				502182	503931		
	Vivaro X 82 & X 83	C	surface				502171	503920		
		C	flush				502172	503921		
		D	surface				502171	503920		
		D	flush				502172	503921		
	Zafira Life	C	surface				503302	503949		
		C	flush				503301	503946		
		B		1	0	0	503303	503950		
		B		1	0	1	503304	503951		
		B		2	1	0	503305	503952		
		B		2	1	2	503306	503953		
Peugeot	Boxer Y	C	surface				502171	503920		
		C	flush				502172	503921		
		W	surface				502179	503928		
		W	flush				502180	503929		
	Expert X	C	surface				502171	503920		
		C	flush				502172	503921		
		W	surface				502177	503926		
		W	flush				502178	503927		
	Expert & Traveller KO	C	surface				503302	503949		
		C	flush				503301	503946		
		B		1	0	0	503303	503950		
		B		1	0	1	503304	503951		
		B		2	1	0	503305	503952		
		B		2	1	2	503306	503953		
	Partner, Tripod/Allied drop floor conversion	B		2	1	2	503461	503954		
Renault	Master X62	B		2	1	2	502039	503909		
		B		2	1	0	502041	503911		
		B		1	0	1	502042	503912		
		B		1	0	0	502043	503913		
		C	surface				502181	503930		
		C	flush				502182	503931		
	Trafic X 82 & X 83	C	surface				502171	503920		
		C	flush				502172	503921		
		D	surface				502171	503920		
		D	flush				502172	503921		
		D	surface				501026	503900		
		D	flush				501027	503901		
Toyota	Proace	C	surface				502171	503920		
		C	flush				502172	503921		
		RD	surface				502177	503926		
		RD	flush				502178	503927		
	Proace & Proace Verso 2017-	C	surface				503302	503949		
		C	flush				503301	503946		
		B		1	0	0	503303	503950		
		B		1	0	1	503304	503951		
		B		2	1	0	503305	503952		
		B		2	1	2	503306	503953		
VW	Caddy, ITEK drop floor conversion	B		2	1	2	503255	503947		
				2	1	0	503310	503948		
	Crafter (2006-2016)	B		2	1	2	501970	503902	√	√
		B		1	0	1	501971	503903	√	√
		B		2	1	0	502034	503905	√	√
		B		1	0	0	502035	503906	√	√
		W	surface				502175	503924		√
		W	flush				502176	503925		√
		D	surface				502171	503920		
		D	flush				502172	503921		
	Crafter 2017 -	C	surface				503142	503941		
		C	flush				503143	503942		
		W	surface				503145	503944		
		W	flush				503144	503943		
		D	surface				502171	503920		
		D	flush				502172	503921		
	VW T5 & T6	B		1	0	1	501973	503904		
		B		1	0	0	502036	503907		
		B		2	1	0	502037	503908		
		B		2	1	2	502040	503910		
		C	surface				502171	503920		
		C	flush				502172	503921		
		W	surface				502173	503922		
		W	flush				502174	503923		
		RD	surface				502177	503926		
		RD	flush				502178	503927		
	T6, Zawatzky Centervan, Drop floor conversion	B		2	1	2	502368	503937		
		B		2	1	0	502369	503938		
	T5 & T6 Colorado, GM Coachwork, Drop floor conversion	B		2	1	2	502285	503933		
		B		1	0	1	502286	503934		
		B		2	1	0	502287	503935		
		B		1	0	0	502288	503936		

SYMBOLS: B-pillar = B / C-pillar = C / D-pillar = D / Window frame = W / Rear door = RD