

Dahl Docking Systems - MK II & VarioDock™

List of vehicles with approved installation kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	MK II	Vario	First seat row			FMVSS 207/ CMVSS 207	FMVSS 210/ CMVSS 210	
						Amount docking stations	Seat base	Shoulder belt anchorage			
Citroën	Berlingo, Tripod/allied drop/floor conversion Jumper Y	B	/	503461	503954	2	1	1			
		C	surface	502171	503920						
		C	flush	502172	503921						
		W	surface	502179	503928						
		W	flush	502180	503929						
	Jumpy X	C	surface	502171	503920						
		C	flush	502172	503921						
		RD	surface	502177	503926						
		RD	flush	502178	503927						
	Jumpy & Spacetourer KO	B		503303	503950	1	0	1			
		B		503304	503951	1	0	1			
		B		503305	503952	2	1	0			
		B		503306	503953	2	1	2			
		C	surface	503302	503949						
C		flush	503301	503946							
	- Freedom Drop Floor Conversion	C (middle)	surface		503665						
Fiat	Doblo high roof SWB & LWB	D	surface	503121	503940						
		D	flush	503120	503939						
	Ducato X250	C	surface	502171	503920						
		C	flush	502172	503921						
		W	surface	502179	503928						
		W	flush	502180	503929						
	Scudo X270	C	surface	502171	503920						
		C	flush	502172	503921						
		RD	surface	502177	503926						
		RD	flush	502178	503927						
	Talento 2016-	C	surface	502171	503920						
		C	flush	502172	503921						
		D	surface	502171	503920						
		D	flush	502172	503921						
Ford	Transit Custom V362	C	surface	502171	503920						
		C	flush	502172	503921						
		RD	surface	502177	503926						
		RD	flush	502178	503927						
	Transit V363	C	surface	502194	503932						
	Jeep MAN	Renegade, ACA Drop floor conversion TGE 2017-	B		501551	501552	2	1	0		
C			surface	503142	503941						
		C	flush	503143	503942						
		W	surface	503145	503944						
		W	flush	503144	503943						
		D	surface	502171	503920						
Mercedes	Vito & V-Class W447	B		502163	503914	2	1	2			
		B		502164	503915	2	1	0			
		B		502165	503916	1	0	1			
		B		502166	503917	1	0	1			
		B		502167	503918	1	0	0			
		B		502168	503919	1	0	0			
		C	surface	502171	503920						
		C	flush	502172	503921						
		RD	surface	502177	503926						
		RD	flush	502178	503927						
		W	surface	503008	503007						
		W	flush	503006	503005						
	Sprinter 906 & 907 & 910	B		501970	503902	2	1	2	√	√	
		B		501971	503903	1	0	1	√	√	
		B		502034	503905	2	1	0	√	√	
		B		502035	503906	1	0	0	√	√	
W		surface	502175	503924					√		
W		flush	502176	503925					√		
Mitsubishi	Express (Australien & New Zealand)	D	surface	502171	503921						
		C	surface	502171	503920						
		C	flush	502172	503921						
		D	surface	502171	503920						
		D	flush	502172	503921						
	Nissan	NV 200	W	surface	503197	503945					
			C	surface	502171	503920					
		NV 300	C	flush	502172	503921					
		D	surface	502171	503920						
	D	flush	502172	503921							
NV 400	B		502039	503909	2	1	2				
	B		502041	503911	2	1	0				
	B		502042	503912	1	0	1				
	B		502043	503913	1	0	0				
	C	surface	502181	503930							
	C	flush	502182	503931							
	Primastar	C	surface	502171	503920						
		C	flush	502172	503921						
		D	surface	502171	503920						
		D	flush	502172	503921						
Opel	Combo High roof SWB & LWB	D	surface	503121	503940						
		D	flush	503120	503939						
	Movano X 62	B		502039	503909	2	1	2			
		B		502041	503911	2	1	0			

Dahl Docking Systems - MK II & VarioDock™

List of vehicles with approved installation kits

Vehicle make	Vehicle model	Position of shoulder belt anchorage	Floor mount type	MK II	Vario	First seat row			FMVSS 207/ CMVSS 207	FMVSS 210/ CMVSS 210
						Amount docking stations	Seat base	Shoulder belt anchorage		
		B		502042	503912	1	0	1		
		B		502043	503913	1	0	0		
		C	surface	502181	503930					
		C	flush	502182	503931					
	Vivaro X 82 & X 83	C	surface	502171	503920					
		C	flush	502172	503921					
		D	surface	502171	503920					
		D	flush	502172	503921					
	Zafira Life	C	surface	503302	503949					
		C	flush	503301	503946					
		B		503303	503950	1	0	0		
		B		503304	503951	1	0	1		
		B		503305	503952	2	1	0		
		B		503306	503953	2	1	2		
Peugeot	Boxer Y	C	surface	502171	503920					
		C	flush	502172	503921					
		W	surface	502179	503928					
		W	flush	502180	503929					
	Expert X	C	surface	502171	503920					
		C	flush	502172	503921					
		W	surface	502177	503926					
		W	flush	502178	503927					
	Expert & Traveller KO	C	surface	503302	503949					
		C	flush	503301	503946					
		B		503303	503950	1	0	0		
		B		503304	503951	1	0	1		
		B		503305	503952	2	1	0		
		B		503306	503953	2	1	2		
	Partner, Tripod/Allied drop floor conversion	B		503461	503954	2	1	2		
Renault	Master X62	B		502039	503909	2	1	2		
		B		502041	503911	2	1	0		
		B		502042	503912	1	0	1		
		B		502043	503913	1	0	0		
		C	surface	502181	503930					
		C	flush	502182	503931					
	Trafic X 82 & X 83	C	surface	502171	503920					
		C	flush	502172	503921					
		D	surface	502171	503920					
		D	flush	502172	503921					
Toyota	Proace	C	surface	502171	503920					
		C	flush	502172	503921					
		RD	surface	502177	503926					
		RD	flush	502178	503927					
	Proace & Proace Verso 2017-	C	surface	503302	503949					
		C	flush	503301	503946					
		B		503303	503950	1	0	0		
		B		503304	503951	1	0	1		
		B		503305	503952	2	1	0		
		B		503306	503953	2	1	2		
VW	Caddy, ITEK drop floor conversion	B		503255	503947	2	1	2		
				503310	503948	2	1	0		
	Crafter (2006-2016)	B		501970	503902	2	1	2	√	√
		B		501971	503903	1	0	1	√	√
		B		502034	503905	2	1	0	√	√
		B		502035	503906	1	0	0	√	√
		W	surface	502175	503924					√
		W	flush	502176	503925					√
		D	surface	502171	503920					
		D	flush	502172	503921					
	Crafter 2017 -	C	surface	503142	503941					
		C	flush	503143	503942					
		W	surface	503145	503944					
		W	flush	503144	503943					
		D	surface	502171	503920					
		D	flush	502172	503921					
	VW T5 & T6	B		501973	503904	1	0	1		
		B		502036	503907	1	0	0		
		B		502037	503908	2	1	0		
		B		502040	503910	2	1	2		
		C	surface	502171	503920					
		C	flush	502172	503921					
		W	surface	502173	503922					
		W	flush	502174	503923					
		RD	surface	502177	503926					
		RD	flush	502178	503927					
	T6, Zawatzky Centervan, Drop floor conversion	B		502368	503937	2	1	2		
		B		502369	503938	2	1	0		
	T5 & T6 Colorado, GM Coachwork, Drop floor conversion	B		502285	503933	2	1	2		
		B		502286	503934	1	0	1		
		B		502287	503935	2	1	0		
		B		502288	503936	1	0	0		

SYMBOLS: B-pillar = B / C-pillar = C / D-pillar = D / Window frame = W / Rear door = RD